

SUBSYSTEM	CCTV	SHUTTLE CCTV FAILURE MODE & EFFECTS ANALYSIS	PREPARED BY J. Calvano	
UNIT	CABLE		DATE 8-12-86	
ASSY. Dwg#	2293288		REVISED 7-12-86	
QUANTITY	1			
<p>FUNCTION: Provides power and commands from cargo bay bulkhead to cargo bay camera stack. supplies video from cargo bay camera stack to cargo bay bulkhead</p>				
ITEM	FAILURE MODE	FAILURE CAUSE	FAILURE EFFECT	FAILURE DETECT
M 5.12	Loss of +28V power RET	Open	: On ESD button : 1) No PTU control; Visual : 2) No video	: FLIGHT/GROUND : None
			: Worst Case: : Loss of mission : critical video.	: TIME AVAIL/REQ : 2/2
			: Worst Case (if video is lost mission critical): : (for B & C cameras only): Unable to verify PLB door soft bulkhead latches are closed.	: CRIT/Y: : HAZARDS/REMARKS : None. : (Usage of EVA tools is available.)